SafetyFirst®

Combination lock
for guns & rifles

Combinatieslot
voor pistolen en geweren

MAKE SURE GUN IS UNLOADED BEFORE PROCEEDING!

1. To open lock, set dials to the user combination. Move the release lever to the up position (unlocked). Pull apart the two sides of the lock.
2. Move the release lever to the down position (locked) and scramble the combination dials.
3. Insert the front of the lock (part with combination dials) through the trigger guard and behind the trigger if possible.
4. With the front of the lock in place insert the rear part of the lock with the outside of both units matching.
5. Once the proper fit is determined, squeeze the two sides together making sure the lock is tight and cannot be moved. Verify this.

SETTING YOUR OWN COMBINATION

1. Open the lock and separate the two sides.
2. Move the release lever to the down position (locked). Factory preset 0-0-0.
3. Apply continuous pressure to the reset button
4. Set the combination dials to your new personal combination.
5. Release the reset button. The new combination is now set. Verify this.

ZORG ERVOOR DAT HET WAPEN ONGELADEN IS VOORDAT U VERDER GAAT!

1. Draai het slot naar de ingestelde gebruikerscode. Beweeg het palletje naar boven (open positie) en trek de twee helften van elkaar.
2. Beweeg het palletje omlaag (gesloten positie) en verdraai de combinatie.
3. Plaats de voorste helft (gedeelte met cijfercombinatie) door de trekkeropening van het wapen. Indien mogelijk, plaats dit achter de trekker.
4. Nadat de voorste helft van het slot in positie zit kan de achterste helft worden geplaatst.
5. Zorg ervoor dat de twee helften goed op elkaar passen. Druk deze vervolgens samen zodat het slot dicht klikt en niet meer kan bewegen. Controleer dit.

GEBRUIKERSCODE INSTELLEN

1. Open het slot en trek de twee helften van elkaar.
2. Beweeg het palletje omlaag (gesloten positie). Fabrieksinstelling is 0-0-0.
3. Druk met een klein en scherp voorwerp de resetknop in aan de linkerzijde van het slot.
4. Verdraai de cijfercombinatie naar de nieuwe gebruikerscode terwijl de resetknop ingedrukt blijft.
5. Als de gewenste nieuwe code is ingesteld kan de resetknop worden losgelaten. De nieuwe gebruikerscode is nu ingesteld. Controleer dit.

SafetyFirst®

8 719326 046693